


Assembly Instructions

Base

- 1** bend two long sides,
then bend back flat

bend against a straight edge e.g. ruler.



- 2** bend two short sides,
then bend back flat




- 3** push in corner sections

easier if you bring the joining short
& long sides up at the same time.



- 4** the base should now
look like this



- 5** fold ends right over
& bend back out

make sure the two folds that are close
together are well & evenly bent.



- 6** push in corners & fold
flap up & over



- 7** press in both corners
to wedge in place


complete the other side



Lid

- 1** pre-bend to begin with

imagine this shape is to fit inside an
invisible bowl.



- 2** fold ends right over
& bend back out


make sure the two folds that are close
together are well & evenly bent




- 3** bend in sides



- 4** lock tabs together



- 5** fold flap up & over




- 6** press in both corners
to wedge in place

complete the other side




Locking Lid

- 1** close lid normally



- 2** fold lid tags into
lower slots on base



Please ensure you do not puncture the bag
The Eco bag's waterproof qualities reduce after 24-48 hours
Keep bags cool & dry, in an airtight container or bag