







FR Configurer le code ES Configurar el código PT Configurar o código IT Impostare il codice
 EL Ρύθμιση κωδικού PL Skonfigurować kod (hasło) RU Настроить код UK Налаштувати код
 RO Configurarea codului EN Setting the code







1



mini 3 maxi 8 + A >  x2 = 

Votre code personnel / Su código personal
 O seu código pessoal / Il vostro codice personale
 Ο προσωπικός σας κωδικός / Twój kod osobisty
 Ваш личный код / Ваш особистий код
 Codul dvs. personal / Your user code

Code incorrect / Código incorrecto / Código incorreto / Codice errato / Εσφαλμένος κωδικός
 / Niepoprawny kod / Неверный код / Невірний код / Cod incorect / Incorrect code





1

3 erreurs  = 
 x3

3 errores / 3 erros / 3 errori / 3 σφάλματα / 3 błędy / 3
 ошибки / 3 помилки / 3 erori / 3 attempts

 20 secondes

20 segundos / 20 segundos / 20 secondi
 20 δευτερόλεπτα / 20 sekund
 20 секунд / 20 секунд / 20 secunde
 20 seconds

2

+ de 3 erreurs  = 
 x3

Más de 3 errores / Mais do que 3 erros / Più di 3 errori /
 Πάνω από 3 σφάλματα / Więcej niż 3 błędy / + 3 ошибки /
 + 3 помилки / Peste 3 erori / More than 3 attempts

 5 minutes

5 minutos / 5 minutos / 5 minuti
 5 λεπτά / 5 minut / 5 минут / 5 хвилини
 5 minute / 5 minutes

